



DESCRIPTION

Lubemaster Radiator flush is a concentrated formula, which will flush grease, oil, sludge, and loose rust in all automotive cooling systems. Safe for Al, copper, porous, iron, steel and rubber parts. No neutralizer needed.

BENEFITS

- Flushes out rust, grease and scale from cooling system.

HOW TO USE

Pour contents of can into full radiator with engine running. Run the engine at fast idle for 10 to 30 mins. Open petcocks and with engine idling run water from hose into radiator first enough to overflow slightly. Do not ADD COLD WATER TO A HOT EMPTY SYSTEM. Flush until water runs clean. Shut off engine and allow system to drain completely. Close petcocks. Refill with fresh anti-freeze coolant and water according to directions.

PROPERTIES

S.No	Properties	Units	Specification
1	Specific gravity @ 68 ° F	-	1.05 - 1.10
2	Flash Point	° F ° C	N/A
3	Boiling Point	° F	N/A
4	Water Solubility	-	100

PACKING INFORMATION

Packing - Plastic Can /355 ml / 12 nos / Secondary box

Storage - Store in Room Temperature. Keep away from Direct UV

(The Information given herein corresponds to the practical experience and to the best of our knowledge. No warranty is expressed or implied regarding accuracy of said data. Owing to differences in local conditions, it is the users responsibility to determine the suitability of the products described herein for their own use. We dis-claim any liability with respect to the use of any material supplied by us).